18PO

## INTEX<sup>®</sup> OWNER'S MANUAL Quick-Fill<sup>™</sup> Electric Air Pump

Model AP626; 12 V DC 8A

READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT


# RNING

Adult use only

INFLATION

- Household use only.
- Do not drop unit into water or expose unit to rain or water.
- Do not direct air stream at face or body.
- Do not operate for more than 15 minutes at a time. Unplug and let cool at least 5 minutes.
- Unplug unit when not in use. Do not obstruct vent holes or open source.
- Do not insert objects into the inflation or deflation connector.
- The DC supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.
- To reduce the risk of electric shock, do not expose to rain. Store indoors.
- . This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

FOLLOW THESE RULES AND ALL INSTRUCTIONS TO AVOID PROPERTY DAMAGE, ELECTRIC SHOCK, BURNS OR OTHER INJURY.



NOTE: Drawings for illustration purpose only. May not reflect actual product. Not to scale.

## **OPERATING INSTRUCTIONS**

1. Attach nozzle to the inflation connector if necessary and hold pump against inflation valve on item to be inflated. See Fig (1).

# READ AND SAVE THESE INSTRUCTIONS 018-\*PO-R0-1504



### **OPERATING INSTRUCTIONS**


NOTE: On large items like inflatable boats and large air mattresses, the pump will fit directly into the inflation valves and provide faster inflation times. Use the appropriate nozzle on small inflation valves as on small air mattresses, etc. 2. Plug in the DC line cord into a car cigarette lighter outlet. See Fig (2).

3. SWITCH ON: Press "I"; SWITCH OFF: Press "0". See Fig (3).



FIG (1): ATTACH NOZZLE






### DEFLATION

1. Attach nozzle to the deflation connector if necessary and hold pump against inflation valve on item to be deflated. See Fig (4)

NOTE: On large items like inflatable boats and large air mattresses, the pump will fit directly into the inflation valves and provide faster deflation times. Use the appropriate nozzle on small inflation valves as on small air mattresses, etc. 2. Plug in the DC line cord into a car cigarette lighter outlet. See Fig (2).

3. SWITCH ON: Press "I"; SWITCH OFF: Press "0". See Fig (3).



#### MAINTENANCE INSTRUCTIONS

No specific air pump maintenance is required. Air pump has no user serviceable parts.

#### MOVING AND STORAGE INSTRUCTIONS

Move the product, air pump and accessories to the power source location. Make sure the power cord is free of twist, kink and knot. Fold the power cord loosely, and return pump and nozzles to package when not in use.



# **READ AND SAVE THESE INSTRUCTIONS**

