
3 IN 1 VALVE INSTRUCTION



A WARNING

- Infants have suffocated on inflatable mattresses. Never place infant aged birth to 15 months to sleep on this inflatable air mattress / air bed. Infants can suffocate on an underinflated or deflated mattress, on bedding, by co-sleeping with another person, and by entrapment between the mattress and bed frame or between the mattress and a vertical surface.
- Children can be entrapped between the inflatable mattress and an adjacent vertical surface. Provide at least a shoulder width space between the inflatable mattress/airbed and adjacent vertical surfaces such as walls. dressers or other objects.
- Always keep the inflatable mattress fully inflated when in use.




TO INFLATE

WITH QUICK-INFLATION VALVE

- 1. Ensure the guick-exhaust and the optional inflation caps are securely tightened.
- 2. Turn the quick-inflation cap fully counterclockwise. See Fig 1-a.
- 3. Pull the quick-inflation cap to open. See Fig 1-b.
- 4. Insert the inflation opening of an air pump directly into the quick-inflation valve. See Fig 2.
- 5. Inflate the product to approximately 80% of desired firmness.

CAUTION: To prevent bursting, do not over inflate or use high pressure air compressor.





SAVE THESE INSTRUCTIONS Page 1

069-*PO-R0-1504

(69PO) 3 IN 1 VALVE ENGLISH 4.875" X 7.25" 04/21/2014

- 6. Align the two " = on the cap with the arrows on both side of the quick-exhaust cap tabs and push in firmly. See Fig 3-a.
- 7. Turn the quick-inflation cap fully clockwise to close. See Fig 3-b.

TO INFLATE WITH OPTIONAL INFLATION VALVE

- 8. Ensure the guick-exhaust and the quick-inflation caps are securely tightened.
- 9. Pull the optional inflation cap tab to open. See Fig 4.
- 10. Insert the nozzle of an air pump into the inflation valve. See Fig 5.
- 11. Inflate the product to approximately 80% of desired firmness.

CAUTION: To prevent bursting, do not over inflate or use high pressure air compressor.


12. Close the optional inflation cap securely after inflation. See Fig 6.

TO ADJUST

- 13. If the product is too firm, open the quick-inflation cap, repeat steps #2 and #3.
- 14. Gently press one of the 3 protruding tabs on the quick-inflation valve to release a small amount of air.

CAUTION: Do not bend or fold down the black rubber diaphragm. See Fig 7.

15. When the desired firmness is achieved, replace the quickinflation cap back. See Fig 3.












SAVE THESE INSTRUCTIONS



TO DEFLATE

- 16. Press the two tabs inwards on each side of the quick-exhaust cap and pull outwards to open. See Fig 8 - 9.
- Fig 8 Fig 9
- 17. For packaging purpose, you may use an air pump to remove the remaining air completely from the airbed. See Fig 10.





18. When the product is completely deflated, replace the quick-exhaust cap back. See Fig 11-a & 11-b.

IMPORTANT: Press down both tabs to ensure the "quick-exhaust cap" is firmly secured onto the sitting base. Notice the "CLICK" sound from both tabs.

> ©2014 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Trading Ltd. - Intex Recreation Corp. All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten. Made in China/Fabriqué en Chine/Hecho en China/Hergestellt in China.

®™ Trademarks used in some countries of the world under license from/®™ Marques utilisées dans certains pays sous licence de/Marcas registradas utilizadas en algunos países del mundo bajo licencia de/Warenzeichen verwendet in einigen Ländern der Welt in Lizenz von/Intex Marketing Ltd. to/ala/an Intex Trading Ltd., Intex Development Co. Ltd., G.P.O Box 28829, Hong Kong & Intex Recreation Corp., P.O. Box 1440, Long Beach, CA 90801 • Distributed in the European Union by/Distribué dans l'Union Européenne par/Distribuido en la unión Europea por/Vertrieb in der Europäischen Union durch/Intex Trading B.V.,

Venneveld 9, 4705 RR Roosendaal – The Netherlands

www.intexcorp.com



SAVE THESE INSTRUCTIONS